

Figure #2

## Position of Head “Frankfort Plane”

While taking height measurements, make sure that the “Frankfort plane” is perpendicular to the measuring rod

